

## Traffic Volume

vs.

## Flow Rate

Can be for ANY time period  
(eq: 1500 Veh. In 30 Min.)

Always expressed in  
**VPH** (Vehicle Per Hour)

(eq: 3000 VPH)

Service Flow Rate  
(Maximum Service Volume)

=

The Highest flow rate that  
can be accommodated at a  
given LOS

### EXAMPLE

| LOS | Service Flow Rate |
|-----|-------------------|
| A   | 600 VPH           |
| B   | 700 VPH           |
| C   | 900 VPH           |
| D   | 1200 VPH          |
| E   | 1400 VPH          |
| F   | -                 |

CAPACITY